



VANITY

INSTALLATION INSTRUCTIONS

INCLUDES INSTRUCTIONS FOR:

Wall Hung Vanity Applications
Floor Standing Vanity Configurations
Aftercare Instructions



VANITY

INSTALLATION INSTRUCTIONS

PLEASE READ CAREFULLY

GENERAL INFORMATION

Thank you for choosing Stein Bathroomware. When you receive your Vanity package please check for any damage. **If damage has occurred advise your supplier immediately and do not proceed with installation otherwise this will invalidate any claim.**

DISCLAIMER

Stein International Ltd is not liable for any Vanity that has not been installed correctly.

INSTALLATION TYPE

- Wall Hung Vanity Installation: Page 2
- Floor Standing Vanity Installation: Page 3

TOOLS REQUIRED

- Drill and drill bits
- Spirit level
- Screw Driver
- Pencil
- Tape Measure
- Caulking gun

MATERIALS REQUIRED

- Screws
- Masking tape
- Silicone sealant
- Cleaning materials

IMPORTANT: INSTALLATION NOTES

- Stein vanities are water resistant but not waterproof. Exposure to excessive moisture by being immediately adjacent to the bath or shower is not recommended. Consult with your merchant supplier if you are in doubt.
- Avoid any distortion to the Vanity due to the walls or floor being out of plumb or level. This will cause the fit of the drawers and doors to be misaligned.
- All tiling must be completed prior to vanity installation. The warranty does not include restoration of tiling or wall finishings.
- Ensure that the hot water supply is regulated to 55 degrees C.
- Fit water flow restrictors to small vanity tops to avoid splashing/overflows.
- Use a professional tradesman for the plumbing connections.

WARRANTY WILL BE VOID IF THE 'INSTALLATION NOTES' ABOVE ARE NOT COMPLIED WITH.

WALL HUNG VANITY INSTALLATION

- 1** Mark the height (from 800mm to 900mm - owners choice) and locate top and bottom frame points to secure the unit.
- 2** **FASTENING TO THE WALL:** Establish two horizontal frames top and bottom so a number of fastening points can be established.
- 3** For installation of pipes it is easier to remove the doors and the drawers. Store them carefully and number their locations.
- 4** Mark and drill holes required for the water and waste fittings.
- 5** Support the unit level at the desired height. Fasten into the frame with heavy gauge wood screws. Use a number of fixing points to fully support the cabinet to the wall.
- 6** Install the plumbing fittings to meet industry standards. Water test the fittings. Use a registered plumber to complete this task.
- 7** Fit the top in place. This should be flush at the back with even overlaps on each side. Check for any rocking movement to the cabinet (mostly applies to ceramic tops). Support this movement and apply a bead of silicone to bond these together.
- 8** Replace and adjust the doors and drawers.
- 9** **SEAL ALL EDGES OF UNIT WITH SILICONE:** Vanity top onto cabinet, top and cabinet to wall and any joints susceptible to water penetration. To achieve an even and tidy finish use masking tape each side of the join.

DO NOT USE FOR 24 HOURS UNTIL SILICONE BOND HAS CURED.

FLOOR STANDING VANITY INSTALLATION

- 1** Check the walls and floors for plumb, level and flat. Take remedial action or compensate for existing discrepancies in the installation process.
- 2** Locate the necessary framework in the wall to secure the cabinet.
- 3** For installation of pipes it is easier to remove the doors and the drawers. Store them carefully and number their locations. NOTE: To release the drawers remove the screws at the front of the sliding channels, lift the drawer at the front and pull forward to release.
- 4** Fasten to the wall with wood screws.
- 5** Fit the top in place. This should be flush at the back with even overlaps on each side. Check for any rocking movement to the cabinet (mostly applies to ceramic tops). Support this movement and apply a bead of silicone to bond these together.
- 6** Install the plumbing fittings to meet industry standards and water test the fittings. Use a registered plumber to complete this task.
- 7** Replace and adjust the doors and drawers.
- 8** **SEAL ALL EDGES OF UNIT WITH SILICONE:** Cabinet to floor, upstand to wall, cabinet and top to wall and any joints susceptible to water penetration. To achieve an even and tidy finish use masking tape each side of the join.

NOTE: CHANELLE CORNER VANITIES

If adding the optional drawer set to the 900 unit, ensure the outer frames are aligned and flush. This is essential to provide sufficient door clearance from the drawers.

DO NOT USE FOR 24 HOURS UNTIL SILICONE BOND HAS CURED.



113 Newton Street, Mount Maunganui
Freephone 0800 002 299
Phone +64 7 928 9990
www.stein.co.nz



AFTERCARE INTRUCTIONS: VANITIES

To comply with Warranty requirements, please ensure the following aftercare procedures are regularly performed. Failure to comply to Warranty Aftercare Instructions will void Warranty.

VITREOUS CHINA BASINS AND VANITY TOPS

- Use warm soapy water or mild detergent and a soft or microfiber cloth. Rinse with clean water.

POLYMARBLE VANITY TOPS

- Use warm soapy water and a clean microfiber cloth followed by drying off with absorbent cloth.
- For minor scuffs on the surface use plastic polish.
- Scratches: If this is minimal use as the process for minor scuffs but in the case of a deeper scratch start with 2000 grit wet and dry paper. Use this wet to take out most of the scratch following on with plastic polish to finish. Note: Deep scratches and chips are best left to a specialised repairer.

VANITY CABINETS

- Laminated or lacquer panted surfaces are water resistant. However constant and excessive exposure to water will enter joins in the assembly and the subsequent damage will be irreparable. Items to comply with warranty:
- Ensure the water pressure is regulated and balanced to the size of the basin to control water splash.
- The water temperature must be at a maximum of 55 degrees Celsius.
- The waste connections have been correctly installed by a licenced plumber.
- Any joins in the cabinet that are susceptible for water ingress must be sealed with silicone including cabinet to wall.
- The bathroom must have a suitable ventilation system to remove moisture vapour.
- All cleaning of surfaces: Use a damp microfiber cloth with warm soapy water followed up by drying off with an absorbent cloth.
- Do not use abrasive or aggressive cleaners.

GENERAL

- A list of chemicals to avoid contact with the surfaces of your product: hair dyes or lacquers, mineral turps, white spirits, insecticides, nail polish or cleaner, bleaches, shoe polish, mercurochrome, iodine, solvents, alcohol, citrus based chemicals, bath oils, bath salts, kerosene. this is by no means comprehensive but indicative of chemical harm that must be avoided.